


Atari 13-Inch Color X-Y Display

(Atari Part No. A200003-01)

Service Manual Complete with Schematics and Illustrated Parts Lists



Manufactured by Amplifone, Inc., Brownsville, Texas—
a wholly owned subsidiary of
Atari, Inc.
790 Sycamore Drive P.O. Box 906
Milpitas, California 95035

© 1983 by Atari, Inc. All rights reserved.

No part of this publication may be reproduced by any mechanical, photographic, or electronic process, or in the form of a phonographic recording, nor may it be stored in a retrieval system, transmitted, or otherwise copied for public or private use, without permission from the publisher.

This technical manual and its accompanying schematic diagrams are protected by the U.S. Copyright Act of 1976.

This Act provides for increased penalties for violating federal copyright laws. Courts can impound infringing articles while legal action is pending. If infringers are convicted, courts can order destruction of the infringing articles.

In addition, the Act provides for payment of statutory damages of up to \$50,000 in certain cases. Infringers may also have to pay costs and attorneys' fees, fines up to \$25,000, and face an imprisonment of up to one year.

Atari will aggressively enforce its copyrights against any infringers. We will use all legal means to immediately halt any manufacture, distribution, or operation of a copy of video games made by us. Anyone who purchases such copies risks forfeiting such a game.

Published by: ATARI, INC. 790 Sycamore Drive P.O. Box 906 Milpitas, California 95035

Printed in the U.S.A. 3M

Notice Regarding Non-ATARI Parts



WARNING



Use of non-ATARI parts or modifications of any ATARI® game circuitry may adversely affect the safety of your game, and may cause injury to you and your players.

You may void the game warranty (printed on the inside back cover of this manual) if you do any of the following:

- substitute non-ATARI parts
- modify or alter any circuits by using kits or parts not supplied by Atari.

ATARI 13-Inch Color X-Y Display

TABLE OF CONTENTS

| 1 | WARNINGS AND CAUTIONS | | | | | |
|---|-----------------------|--|--------|--|--|--|
| | A. | Before You Start | 2 | | | |
| | B. | Safety Measures | | | | |
| | C. | Cathode-Ray Tube Handling | 2 | | | |
| | D. | Replace with Proper Components | | | | |
| | E. | Final Testing Before Reinstalling Display Assemblies | 3 | | | |
| 2 | SPE | CIFICATIONS | | | | |
| | A. | Input Information | 4 | | | |
| | B. | Z Bandwidth | 4 | | | |
| | C. | High Voltage | 4 | | | |
| | D. | Controls | 4 | | | |
| 3 | DET | AILS OF OPERATION | | | | |
| | A. | Low-Voltage Power Supply | 5 5 | | | |
| | в. | High-Voltage Power Supply | | | | |
| | c. | Over-Voltage Protection | 5 | | | |
| | D. | X and Y Deflection Amplifiers | 7 | | | |
| | E. | Input Protection | 7 | | | |
| | F. | Z Amplifiers (Red, Green, and Blue) | 7 | | | |
| | G. | Spot Killer (Blanking) | 8 | | | |
| 4 | REP | AIR | | | | |
| | A. | Cathode-Ray Tube Replacement | 9 | | | |
| | B. | Yoke Replacement | 10 | | | |
| | C. | Neck PCB Replacement | 10 | | | |
| | D. | Deflection PCB Replacement | 11 | | | |
| | E. | High-Voltage Transformer Replacement | 11 | | | |
| 5 | CON | TROL ADJUSTMENTS | | | | |
| | A. | Focus Adjustment | 12 | | | |
| | B. | Brightness | 12 | | | |
| | C. | Purity Adjustments | 12 | | | |
| | D. | Convergence Adjustments | 16 | | | |
| | E. | Tracking Adjustments | 19 | | | |
| | F. | High-Voltage Power Supply Adjustments | 19 | | | |
| | | | | | | |

ATARI 13-Inch Color X-Y Display

| 6 | ILLUSTRATED | PARTS LISTS | 23 |
|------|-------------|---|----|
| | | LIST OF ILLUSTRATIONS | |
| Figu | re l | Display Block Diagram | 6 |
| Figu | re 2 | Adjustable Controls on the Neck PCB | 13 |
| Figu | re 3 | Purity and Convergence Adjustments | 15 |
| Figu | re 4 | Adjustable Controls on the Deflection PCB | 18 |
| Figu | re 5 | Cathode—Ray Tube Assembly | 22 |
| Figu | re 6 | Deflection PCB Assembly | 24 |
| Figu | re 7 | Neck PCB Assembly | 30 |
| Figu | re 8 | Wiring Diagram | 33 |
| Figu | | Deflection PCB Schematic Diagram | 34 |
| _ | re 10 | Neck PCB Schematic Diagram | 36 |

1 WARNINGS AND CAUTIONS

This color X-Y display has been built to Atari specifications by Amplifone, Inc. This display is not contained within a separate chassis; instead, the printed-circuit board (PCB) and the cathode-ray tube assembly (CRT) are separately mounted inside the game cabinet. Input signals for the display are supplied through a 15-pin harness connector that is wired to the Deflection PCB.

This display operates similarly to those used in ATARI black-and-white X-Y video games, such as Asteroids®, Battlezone®, or Red Baron™. However, this display has three Z amplifiers for controlling the three color guns of the cathode-ray tube. This tube is a 90-degree, in-line gun, stripe-phosphor, color cathode-ray tube.

A WARNINGS

High Voltage

This display contains high voltages capable of delivering lethal quantities of energy. To avoid danger, do not attempt to service the display until you have observed all precautions necessary for working on high-voltage equipment.

X-Radiation

This display has been designed for minimum X-radiation hazard. To reduce risk of possible exposure to X-radiation, take X-radiation protective measures for personnel during servicing. It is imperative that you never modify the high-voltage circuity.

Implosion Hazard

The high vacuum cathode-ray tube is dangerous to handle. If you drop the cathode-ray tube and it breaks, it will implode! Shattered glass can fly 6 feet or more from the implosion site. Use care when replacing the cathode-ray tube.

A. Before You Start

Never attempt to work on a display until you are familiar with servicing precautions and procedures necessary for high-voltage equipment. Remember, any video display has at least three sources of possible danger:

- 1. Strong electric shock, due to high voltage or AC line voltage
- 2. X-ray radiation (when the display is out of adjustment)
- 3. Implosion

Therefore, never modify any circuit in this display.

Perform servicing on a video display only after you are thoroughly familiar with all warnings and safety measures given in this chapter.

B. Safety Measures

Good safety habits will allow you to automatically take the proper precautions, even if you are rushed. Whenever you work on a display assembly, always ground it first. Also, use only one hand. This avoids the possibility of carelessly putting one hand on electrical ground and the other on an electrical connection, which could cause a severe electrical shock.

If you service the ATARI 13-Inch Color X-Y Display on a test bench, use only the power supply that came with the game. (Refer to the parts list in the game manual for the Atari part number of the Power Supply Assembly for Color X-Y Games). Do not use line voltage or a power supply from a black-and-white X-Y game because the voltages produced by those sources will damage this display.

To prevent fire or shock hazard, never expose this display to moisture.

Periodically check for frayed insulation on wires. If frayed wires are found, replace them with the same gauge, insulation type, thickness, and length of wire. Always observe the original lead dress (routing and length of harness wires).

Use extra precaution in the high-voltage circuitry areas of the display. If a short circuit occurs, replace any components that indicate they may have overheated.

C. Cathode-Ray Tube Handling

Wear safety goggles and heavy gloves for protection whenever you handle a cathode-ray tube. Keep other people away if they are not wearing safety goggles. Never lift the cathode-ray tube by the neck; the neck should only be used to guide the lifting process.

Use extreme care when handling the cathode-ray tube. Rough handling may cause the tube to implode. Do not nick or scratch the glass or subject any undue pressure upon the tube at any time.

If servicing the cathode-ray tube, first discharge the high voltage on the anode connection to ground—not to the cabinet or other mounting parts. When discharging the anode, use a well-insulated 18-guage jumper wire. Allow two minutes to pass and discharge the anode again.

D. Replace with Proper Components

Maintain the specified values of all components within the display. Failure to do this could cause a rise in the high voltage.

The cathode-ray tube of this display employs integral implosion protection. For continued safety, replace it only with a tube of the same type number. Refer to the parts lists in Chapter 6 of this manual. Use only exact replacement parts, especially for those parts identified in the parts lists with the \(\Delta \) symbol and on the schematics with shading.

E. Final Testing Before Reinstalling Display Assemblies

Before reinstalling any assembly of this color display, inspect all harness wiring within the display area. Be sure no wires or cables are pinched between the cabinet and other parts in the display.

2 SPECIFICATIONS

A. Input Information

Input Voltage 50 VAC RMS (center tapped, 25-0-25), within

+10, -15%.

X-Amplifier Input 16 V peak-to-peak (±8 V) for 10.5 inches of Voltage

deflection.

Y-Amplifier Input

Voltage

12 V peak-to-peak (±6 V) for 8 inches of deflection.

Z-Amplifier Drive +3.5 V for maximum intensity; 1.0 V for black level.

Input Impedance:

X Amplifier 3.3 kilohms

Y Amplifier 2.2 kilohms

Z Amplifiers 2.2 kilohms

B. Z Bandwidth

8 MHz at -3 dB down.

C. High Voltage

19.5 kV at 0 beam current.

D. Controls

Factory Adjusted Brightness, High-Voltage Adjustment, and all Bias and

Drive adjustments for the Z Amplifiers.

Operator Adjustable Focus

3 DETAILS OF OPERATION

A basic block diagram of the circuitry within this display is shown in Figure 1. Refer to this illustration and the schematic diagrams while you read this section.

A. Low-Voltage Power Supply

Input voltage of 50 VAC is applied to the bridge rectifier (CR1, CR2, CR3, CR4) through fuses Fl and F2. The bridge circuit converts the AC input voltage into an unfiltered DC voltage. Capacitors C5 and C8 form the first stage of filtering for the \pm 30 VDC provided by the bridge.

The input voltage is also applied to the degaussing circuit if posistor PTCl is cool. This occurs when power is initially applied to the display. At this time the current flowing through the degaussing coil will degauss the cathode-ray tube (CRT). However, after PTCl becomes heated, current is removed from the degaussing coil, making it inoperative.

The +30 V and -30 V are applied to regulators U1 and U2. These electronic regulators provide stable DC voltages of +24 V and -24 V.

B. High-Voltage Power Supply

Oscillator U3 provides a squarewave output at pin 3 that runs at about 20 kHz. Variable resistor R54 (off pin 6 of U3) sets the operating frequency of this oscillator. The output from U3 drives current amplifiers Q25 and Q26. These, in turn, drive the primary of transformer T1. Transformer T1 is a step-down type that is used to increase the current.

Transistor Q24 provides more amplification of the current before the 20-kHz signal is applied to the primary of high-voltage transformer T2. The outputs from the secondary of T2 provide the Video B+ of +180 volts, the CRT heater voltage, and the +19.5-kV supply for the CRT anode. The FOCUS and BRIGHTNESS adjustments are also off the secondary of T2.

C. Over-Voltage Protection

The over-voltage protection circuit monitors the voltage at pin 4 of the focus assembly. If this voltage increases, SCR Q23 will fire, turning off oscillator U3. This shuts off the high-voltage power supply.




Figure 1 Display Block Diagram

D. X and Y Deflection Amplifiers

- NOTE -

Because the X and Y deflection amplifiers are similar in operation, only the Y deflection amplifier is described here.

The Y deflection amplifier processes the Y signals developed by the game circuitry and provides final amplification to drive the Y deflection coil of the CRT. The Y input signal is applied to the base of Q6, which is connected as a differential amplifier with transistor Q7. Constant current for this differential amplifier is supplied by Q8.

After amplification by Q6 and Q7, the Y signal is applied through driver Q13 to the emitter-follower pair of Q14 and Q15. The Y signal from the emitters of Q14 and Q15 is then applied through fuse F3 to the Y deflection coil of the CRT. Transistor Q16 is the constant-current source for driver Q13.

E. Input Protection

The input protection circuit monitors the average DC level of the X and Y input signals from the game circuitry. If either of these signals is excessive, the input protection circuit will turn off the X and Y deflection amplifiers, which enables the spot killer circuit to turn off the Z amplifiers.

The Y input signal is applied through Rl to the bases of Ql and Q2, and the X input signal is applied through R3 to the bases of Q3 and Q4. If either vertical or horizontal deflection is excessive in average DC level, at least one of transistors Ql through Q4 will turn on. This turns off Q5, which then shuts down the X and Y deflection amplifiers.

F. Z Amplifiers (Red, Green, and Blue)

- NOTE -

The Z amplifiers are located on the Neck PCB. Because the red, green, and blue amplifiers are similar in operation, only the red amplifier is described here.

Transistors Ql through Q3 comprise a cascode amplifier that provides the final amplification for the red intensity signal from the game circuitry. Variable resistor R8 is the RED DRIVE adjustment and sets the amount of gain in this stage. Variable resistor R11 is the RED BIAS adjustment and is used to set the cutoff characteristics of this stage. The amplified signal from the collector of Q3 is applied across R10 to the red cathode gun of the CRT.

When the spot killer is turned on, transistor Q10 will turn off the Z amplifiers.

G. Spot Killer (Blanking)

The spot killer circuit turns off all three of the Z amplifiers whenever deflection is not occurring. This prevents the electron beams from burning the phosphor on the inside of the CRT.

The input signals to the spot killer circuit are taken off the X and Y deflection amplifiers from current-sensing resistors R18 and R30. These sample deflection voltages are rectified and filtered by CR19 and CR20 (for the Y signal) and by CR21 and CR22 (for the X signal). Then they are applied to the bases of Q17 and Q18.

Anytime either deflection amplifier is not driving current through the CRT deflection coils, then that side of the spot killer will not be receiving a sample signal. This lack of signal on the base of either Q17 or Q18 will turn on that transistor. When either Q17 or Q18 conducts, Q9 will also conduct. The signal at the emitter of Q9 causes CR15 to illuminate, indicating that the spot killer is on. From the cathode of CR15, the spot killing signal is applied to the base of Q10 (located on the Neck PCB). When Q10 turns off, the Z amplifiers are turned off.

4 REPAIR



Before removing or installing any component of this display, always disconnect the power source! Observe the precautions regarding high voltages and cathode-ray tube handling when servicing this display.

Tools Required to Replace the Display Assemblies: Phillips-head screwdriver.

A. Cathode-Ray Tube Replacement

- NOTE -

You must readjust the BRIGHTNESS control whenever the cathode-ray tube is replaced.

- 1. Disconnect the 15-pin video-signal connector, which is wired to the Deflection PCB.
- 2. Unplug the Neck PCB from the rear of the cathode-ray tube.
- 3. Discharge the high voltage from the cathode-ray tube as follows:
 - a. Attach one end of a well-insulated 18-gauge jumper wire to the Dag spring.
 - b. Momentarily touch the free end of the jumper to the anode by sliding it under the anode cap.
 - c. Wait two minutes.
 - d. Discharge the anode again.
 - e. CAREFULLY remove the large high-voltage anode connector from the cathode-ray tube.
- 4. Unplug the degaussing coil 2-pin connector from the Deflection PCB.
- 5. Unplug the yoke 5-wire connector from the Deflection PCB.
- 6. Unhook the spring that runs across the back of the cathode-ray tube.

- 7. Remove the four screws holding the cathode-ray tube.
- 8. CAREFULLY remove the cathode-ray tube by easing it out the front of the cabinet. Refer to the operators manual for your product for complete instructions on how to perform this step.
- 9. Place the cathode-ray tube on a soft mat in a protected location.
- 10. To install a cathode-ray tube, reverse the order of this procedure.

B. Yoke Replacement

- NOTE -

You must reconverge the picture and readjust the purity whenever the yoke is replaced.

- 1. Disconnect the 15-pin video-signal connector which is wired to the Deflection PCB.
- 2. Unplug the Neck PCB from the rear of the cathode-ray tube.
- 3. Discharge the high voltage from the cathode-ray tube using the procedure given in step 3 under Cathode-Ray Tube Replacement.
- 4. Use a thin knife or a single-edged razor blade to carefully loosen the rubber wedges (located under the yoke) from the cathode-ray tube surface. Remove the magnetic strips, if any.
- 5. Loosen the screws that are used to tighten the convergence-magnet assembly and yoke assembly clamps around the neck of the cathode-ray tube.
- 6. Slide the convergence-magnet assembly and yoke assembly off the end of the cathode-ray tube.
- 7. To replace a yoke assembly, reverse the order of this procedure. Replace the magnetic strips only if complete convergence cannot be obtained with the convergence magnets.

C. Neck PCB Replacement

- 1. Disconnect the 1-pin focus-wire connector from the Neck PCB.
- 2. Unplug the Neck PCB from the rear of the cathode-ray tube.
- 3. Unplug the connector from the Dag spring.
- 4. Disconnect the 14-pin video-signal connector at the Neck PCB.

5. To install a Neck PCB, reverse the order of this procedure.

D. Deflection PCB Replacement

- 1. Disconnect the 15-pin video-signal connector, which is wired to the Deflection PCB.
- 2. Unplug the 9-pin and 4-pin connectors from the Neck PCB; the 2-pin connector from the deguassing coil; the 5-pin connector from the yoke; and the individual wires to the Dag spring, cathode-ray tube socket, and anode. See step 3 under Cathode-Ray Tube Replacement.
- 3. Remove the two Phillips-head screws securing the Deflection PCB to the cabinet.
- 4. Slide the Deflection PCB from the cabinet.
- 5. To install the Deflection PCB, reverse the order of this procedure.

E. High-Voltage Transformer Replacement

- 1. Remove the Deflection PCB from the cabinet as previously described under Deflection PCB Replacement.
- 2. Unsolder the white wire at the top of the focus assembly.
- 3. Remove the four sheet-metal screws that attach the high-voltage cage cover to the display.
- 4. Remove the two small hex nuts that secure the transformer to the Deflection PCB.
- 5. Unsolder the seven transformer connections on the bottom of the Deflection PCB.
- 6. Lift the transformer off the Deflection PCB.
- 7. Replace the transformer by reversing this procedure. Be sure to check the picture for sharpness. If appropriate, adjust FOCUS.

5 CONTROL ADJUSTMENTS



Remember to observe the precautions regarding high voltages when making adjustments on this display!

A. Focus Adjustment

The FOCUS control (FAI) should be adjusted if the screen image is not sharply defined. Figure 4 shows the location of the FOCUS control. Turn this control until you get optimum screen sharpness; then readjust for a slightly defocused image to enlarge the line size. This is the only control not preset by the factory.

B. Brightness

The BRIGHTNESS control (R31) is set at the factory and then sealed. Do not adjust the BRIGHTNESS control unless the cathode-ray tube is replaced. Figure 2 shows the location of the BRIGHTNESS control. To adjust, follow the steps below.

- 1. Turn on the display. Allow it to warm up for at least 5 minutes.
- 2. Place the game in the attract or play mode.
- 3. Use a screwdriver to adjust the display for a pleasing level of brightness or adjust as indicated in the color-level test given in the appropriate game manual.

C. Purity Adjustments

- NOTE -

The Convergence Adjustments <u>must</u> be performed after completion of the Purity Adjustments.

- 1. Remove power from the display.
- 2. Loosen the screws that are used to tighten the deflection yoke and convergence-magnet assembly clamps to the neck of the cathode-ray tube.




Figure 2 Adjustable Controls on the Neck PCB

- 3. Remove any glue that may be holding the purity magnets in place.
- 4. Use a razor blade or thin knife to carefully loosen the glue holding the three rubber wedges beneath the yoke collar. Remove these wedges.
- 5. Position the cabinet so that the cathode-ray tube faces either north or south.
- 6. Degauss the cathode-ray tube with a hand-held degaussing coil.
- 7. Apply power to the display.
- 8. Position the convergence-magnet assembly so that the purity rings shown in Figure 3 are positioned directly over the gap in the cathode-ray tube gun assembly. This is about two inches forward from the start of the neck glass.
- 9. Secure the convergence-magnet assembly in position by tightening the neck-clamp mounting screw.
- 10. Set the game to display the self-test diagnostic pattern that shows a vertical and horizontal crosshatch with all three colors. This may appear as a white crosshatch pattern on the screen. (Refer to the Self-Test Procedures in the game manual for details on selecting self-test diagnostic patterns.)
- 11. Preset the convergence magnets to superimpose the red, blue, and green lines at the center of the screen.
- 12. Set the game to display only the green crosshatch diagnostic pattern.
- 13. Slide the deflection yoke toward the magnet assembly to produce a vertical green band within the center of the crosshatch pattern.
- 14. Adjust the purity rings of the magnet assembly shown in Figure 3 so that the width of the green band is horizontally equal to the red and blue bands on either side.

- NOTE -

The purity rings must only affect the horizontal centering of the display. If they have a vertical or a diagnal centering effect, rotate the entire magnet assembly so that the purity rings affect ONLY the horizontal centering.

15. Slide the deflection yoke forward until the crosshatch pattern is entirely green. Continue the forward movement of the yoke until other colors begin to show on the display. This is the forward purity-adjustment limit of the yoke.




Figure 3 Purity and Convergence Adjustments

- 16. Slide the yoke back toward the magnet assembly through the position for a pure green display to the point where the display again begins to show other colors. This is the rear purity-adjustment limit of the yoke.
- 17. Position the deflection yoke to the middle of the forward and rear purity-adjustment limits. Tighten the yoke-mounting screw.
- 18. Set the game to display the red and green crosshatch diagnostic patterns.
- 19. Check the display for good overall purity.
- 20. Perform the Convergence Adjustments.
- D. Convergence Adjustments

- NOTE -

If the Purity Adjustments have been performed, you must also perform the entire Convergence Adjustments procedure.

- 1. Adjust for static convergence, which aligns the registration of all three colors over the entire screen area, as follows:
 - a. Set the game to display the self-test diagnostic pattern that shows a magenta (both red and blue) crosshatch. (Refer to the Self-Test Procedures in the game manual for details on selecting self-test diagnostic patterns.)
 - b. Adjust the angle of the tabs of the red and blue convergence magnets to superimpose the red and blue vertical lines in the center of the screen area. This will produce magenta vertical lines at screen center. These magnets are shown in Figure 3.

- NOTE -

Do not attempt to adjust the convergence of the outer areas of the screen at this time.

c. Keeping their angles the same, rotate both tabs of these magnets to superimpose the red horizontal lines with the blue horizontal lines in the center of the screen area. This produces magenta horizontal lines at screen center.

- d. Set the game to display the diagnostic crosshatch pattern composed of all three colors. (This may appear as a single white crosshatch pattern.)
- e. Adjust the angle between the tabs of the green convergence magnets to superimpose the green vertical lines with the magenta vertical lines already converged in the center of the screen.
- f. Keeping the tab angles the same, rotate these rings to superimpose the green horizontal lines on the magenta horizontal lines already converged in the center of the screen.
- 2. Adjust for peripheral convergence, which aligns the registration of all three colors at the outer areas of the screen, as follows:
 - a. If not already done as part of the Purity Adjustments, loosen the screw securing the deflection yoke assembly to the neck of the cathode-ray tube. Then, use a razor blade or thin knife to loosen the glue holding the three rubber wedges beneath the collar of the yoke. Remove these wedges.
 - b. Set the game to display the magenta (both red and blue) crosshatch diagnostic pattern.
 - c. Tilt the deflection yoke in a vertical direction to superimpose the red horizontal lines with the blue horizontal lines at the 3 o'clock and 9 o'clock positions of the screen.
 - d. While maintaining the vertical position of the yoke, tilt it in a horizontal direction to superimpose the red crosshatch with the blue crosshatch pattern at the 6 o'clock and 12 o'clock positions of the screen.
 - e. Install the three rubber wedges firmly beneath the yoke collar to hold the yoke in position. Recheck the convergence of the display. If necessary, repeat parts c and d of this procedure.
 - f. Set the game to display the crosshatch diagnostic pattern composed of all three colors (this should appear as a white crosshatch pattern).
 - g. Check the display for good convergence at all areas of the screen. If necessary, repeat the static convergence adjustments of step 1.
- 3. Secure the rings of the convergence-magnet assembly and the rubber yoke wedges with white glue.
- 4. Tighten the deflection-yoke mounting screw.




Figure 4 Adjustable Controls on the Deflection PCB

E. Tracking Adjustments

- 1. Set the game to display the self-test diagnostic pattern that shows a series of colored bars of various intensities.
- 2. Turn all Bias and Drive controls to their fully clockwise position. Refer to Figure 2 for the location of these controls.
- 3. Adjust RED BIAS R11, GREEN BIAS R21, and BLUE BIAS R30 until the fifth line from the right in the center group of lines is pure white.
- 4. Adjust RED DRIVE R8, GREEN DRIVE R18, and BLUE DRIVE R27 until the far right line of the center group of lines is pure white.
- 5. If the fifth line from the right is no longer pure white, repeat step 3 of this procedure.

F. High-Voltage Power Supply Adjustments



To avoid possible electric shock, use extreme caution when making these high-voltage adjustments! Do not attempt to make these adjustments without the high-voltage probe!

- 1. Remove power from the display.
- 2. Attach the minus lead of the high-voltage probe to the Dag spring.
- 3. Connect the high-voltage probe to the anode connection of the cathoderay tube by slipping it under the anode cap.
- 4. Apply power to the display.
- 5. Rotate HV OVER-VOLTAGE R62 to its fully counterclockwise position. Figure 2 shows the location of the HV OVER-VOLTAGE and FREQUENCY controls.
- 6. Rotate FREQUENCY R54 for a reading of +25 kV on the voltmeter.
- 7. Very slowly rotate HV OVER-VOLTAGE R62 until the voltmeter reading just drops to 0 and HV Trip LED CR25 illuminates.
- 8. Turn the display power OFF and then ON. This resets the over-voltage protection circuit.
- 9. Readjust the FREQUENCY control for a voltmeter reading of +19.5 kV.

10. Remove power from the display and then remove the high-voltage probe from the anode connection.

6 ILLUSTRATED PARTS LISTS


This chapter provides the necessary information for you to order parts for your ATARI 13-Inch X-Y Display. Please note that, for simplicity, common hardware has been deleted from most of the parts lists. This includes screws, nuts, washers, and bolts.

The PCB parts lists are arranged in alphabetical order by component type. Each component subsection is arranged alphanumerically by reference designator.

Other parts lists are arranged alphanumerically by Atari part number. For example, all "A-" prefix numbers come first. Following these are numbers in sequence evaluated up to the hyphen, namely 00- thru 99-, then 000598- thru approximately 201000.

When ordering parts, please give the part number, part name, applicable figure number of this manual, and serial number of your display. This will help to avoid confusion and mistakes in your order.

Atari Customer Service numbers are listed in the front of this manual for your convenience.






Figure 5 Cathode-Ray Tube Assembly

Cathode-Ray Tube Assembly A201074-01 1

| A | A201020-02 A201044-01 A201075-01 A201078-01 | Neck Board Assembly Magnetic Shunt Assembly Yoke Assembly Dag Spring Assembly |
|----------|--|---|
| | A201081-01 038643-01 134003-001 150006-699 | Degaussing Coil Assembly Color X-Y CRT Mounting Bracket Type-13VBSP22 13-Inch 90-Degree Color Cathode-Ray Tube #20 AWG Bare Tinned Copper Bus Wire |
| | 171010-001 178058-001 201085-01 | CRT Convergence Ring Deflection Yoke Wedge Label |




Figure 6 Deflection PCB Assembly

FAl

Focus Assembly

Deflection PCB Assembly A201066-01 3

Assemblies

A201068-01

| FAI | (Assembly consists of: 201011-01—Focus Mounting Bracket, 171008-001—Focus Control, A201059-02—Lead Wire Assembly, 201060-01—Jumper Wire, 201060-02—Jumper Wire, and 178064-001—Insulating Boot) | A201000 01 |
|-----------------|---|--|
| MC1 T1 T2 | Ind./Reactive Voltage Regulator Assembly Driver Transformer Assembly Ultra Tuned I.F.T.M. Assembly | A201006-01 A201008-01 A201005-01 |
| Q24 | Harness Assembly High-Voltage Cage Assembly Fan Power Harness Assembly High-Voltage Transistor/Bracket Assembly (Assembly consists of: 133005-001-400 V, 7 A, NPN Power Transistor; 201091-01-High-Voltage Transistor Bracket; 178109-001-Mica Insulator; and 175000-055-Shoulder Washer) | A201070-01 A201071-01 A201089-01 A201090-01 |
| | Capacitors | |
| ca, c2 | 100 uF, 25 V, Radial-Lead Aluminum Electrolytic | 123003-107 |
| C3, C4 | Capacitor 0.1 uF, +80%, -20%, 50 V Minimum, Axial-Lead Ceramic Capacitor | 122002-104 |
| C5 | 4700 uF, 50 V, Vented, Radial-Lead Aluminum Electro- lytic Capacitor | 123001-478 |
| C6 | 0.1 uF, +80%, -20%, 50 V Minimum, Axial-Lead Ceramic Capacitor | 122002-104 |
| C 7 | 100 uF, 35 V, Vented, Radial-Lead Aluminum Electro -lytic Capacitor | 123000-107 |
| c 8 | 4700 uF, 50 V, Vented, Radial-Lead Aluminum Electro- lytic Capacitor | 123001-478 |
| C 9 | 0.1 uF, +80%, -20%, 50 V Minimum, Axial-Lead Ceramic | 122002-104 |
| C10 | Capacitor 100 uF, 35 V, Vented, Radial-Lead Aluminum Electro- lytic Capacitor | 123000–107 |
| Cl1 Cl2 | 0.056 uF, 400 V Metallic/Polyester Capacitor 0.0047 uF, ±10%, 50 V Minimum, Axial-Lead Ceramic Capacitor | 121009-563 122015-472 |

| C16 | Capacitor 0.0047 uF, ±10%, 50 V Minimum, Axial-Lead Ceramic Capacitor | 122015-472 |
|---------------------------------------|--|--|
| C17, C18 | | 122002-104 |
| C19 C20 | 0.47 uF, 100 V Radial-Lead Mylar Capacitor 0.1 uF, +80%, -20%, 50 V Minimum, Axial-Lead Ceramic | 21-101474 122002-104 |
| C2 1 | 0.47 uF, 50 V, Radial-Lead Aluminum Electrolytic Cap- Capacitor | 123001-474 |
| C22-C25 | 0.47 uF, 50 V, Aluminum Electrolytic Axial-Lead Cap- | 124001-474 |
| C26 | 0.47 uF, 50 V, Radial-Lead Aluminum Electrolytic | 123001-474 |
| C27 C28 | 0.47 uF, 100 V Radial-Lead Mylar Capacitor 0.1 uF, +80%, -20%, 50 V Minimum, Axial-Lead Ceramic Capacitor | 21-101474 122002-104 |
| C2 9 | 4.7 uF, 50 V Axial-Lead Aluminum Electrolytic | 24-500475 |
| C30 C31, C32 | 0.0047 uF, 100 V Radial-Lead Mylar Capacitor 0.01 uF, +80%, -20%, 50 V Minimum, Axial-Lead Cera- | 21-101472 122014-103 |
| C33 | 0.001 uF, ±10%, 1 kV, Radial-Lead Ceramic Capacitor | 121012-102 |
| C34 | 0.1 uF, +80%, -20%, 50 V Minimum, Axial-Lead Ceramic | 122002-104 |
| C35 | 0.033 uF, ±5%, 600 V, Radial-Lead Polyproplene Capacitor | 121011-333 |
| යා යා යා යා යා | 47 uF, 50 V Axial-Lead Aluminum Electrolytic Capacitor 0.001 uF, ±10%, 1 kV, Radial-Lead Ceramic Capacitor 10 uF, +50%, -20%, 200 V, Radial-Lead Aluminum Electrolytic Capacitor | 24–500476 121012–102 123007–106 |
| | Diodes | |
| CR1-CR4 CR5-CR7 CR8 CR9-CR12 | 100 V, 6 A, Plastic Diode MR751 Type-lN914, 100V, 250 mW Switching Diode Type-lN751A, 5.1 V, +5%, 500 mW Zener Diode Type-lN4001, 50 V Switching Diode | 131007-001 31-1N914 32-1N751A 31-1N4001 |
| CR15 | Type-MV5053 Light-Emitting Diode | 31-1N914 38-MV5053 31-1N914 38-MV5053 |
| CR26 CR27 CR28 Q23 | Type-1N754A, 6.8 V, ±5%, 400 mW Zener Diode 1000 V, 1A, Fast Recovery Rectifier Diode MR818 Type-1N5245B, 15 V, 500 mW Zener Diode 100 V, 0.8 A, Silicon Controlled Rectifier | 131002-001 131004-001 131016-001 131005-003 |
| | C17, C18 C19 C20 C21 C22-C25 C26 C27 C28 C29 C30 C31, C32 C33 C34 C35 C36 C37, C38 C39 CR1-CR4 CR5-CR7 CR8 CR9-CR12 CR13, CR14 CR15 CR16-CR24 CR25 CR26 CR27 CR28 | C17, C18 |

C14, C15 0.1 uF, +80%, -20%, 50 V Minimum, Axial-Lead Ceramic 122002-104

Diode MCR100-3

Integrated Circuits

| U1 | 24 V, 1 A, Fixed Voltage Regulator 7824 | 137183-001 |
|----------------|---|--|
| U2 | -24 V, 1 A, Fixed Voltage Regulator 7924 | 137220-001 |
| U3 | Integrated Circuit Timer LM555 | 37-555 |
| | Resistors | |
| PTCl | 3 Ω, 60 V, ±10%, Positive-Temperature-Coefficient Resistor | 110012-030 |
| R1 R2 R3 | 82 kΩ, ±5%, 1/4 W Resistor 10 kΩ, ±5%, 1/4 W Resistor 100 kΩ, ±5%, 1/4 W Resistor | 110000-823 110000-103 110000-104 |
| R4 | 10 k Ω , ± 5 %, $1/4$ W Resistor | 110000-103 |
| R5 | 680 Ω , ± 5 %, $1/4$ W Resistor | 110000-681 |
| R6 | 1.5 k Ω , ± 5 %, $1/4$ W Resistor | 110000-152 |
| R7 | 1 k Ω , ± 5 %, $1/4$ W Resistor | 110000-102 |
| R8, R9 | 22 k Ω , ±5%, 1/4 W Resistor | 110000-223 |
| R10 | 1.8 k Ω , ±5%, 1/4 W Resistor | 110000-182 |
| R11 | 22 k Ω , ±5%, 1/4 W Resistor | 110000-223 |
| R12 | 1.5 k Ω , ±5%, 1/4 W Resistor | 110000-152 |
| R13 | 22 Ω , ±5%, 2 W, Metal-Film Resistor | 110010-220 |
| R14 | 390 Ω , ±5%, 1/4 W Resistor | 110000-391 |
| R15 | 10 Ω , ±5%, 1/4 W Resistor | 110000-100 |
| R16 | 390 Ω , ±5%, 1/4 W Resistor | 110000-391 |
| R18 | 1.5 Ω , ±5%, 10 W, Wire-Wound Resistor | 116003-001 |
| R19 | 2.7 $k\Omega$, ±5%, 1/2 W Resistor | 110001-272 |
| R20 | 100 Ω , ±5%, 1/4 W Resistor | 110000-101 |
| R21 | 91 Ω , ±5%, 1/4 W Resistor | 110000-910 |
| R22 | 4.7 kΩ, $\pm 5\%$, $1/2$ W Resistor | 110001-472 |
| R23 | 2.2 kΩ, $\pm 5\%$, 1 W Resistor | 110009-222 |
| R24 | 15 kΩ, $\pm 5\%$, $1/4$ W Resistor | 110000-153 |
| R25 | 33 kΩ, $\pm 5\%$, $1/4$ W Resistor | 110000-333 |
| R26 | 2.2 k Ω , ±5%, 1/4 W Resistor | 110000-222 |
| R27 | 390 Ω , ±5%, 1/4 W Resistor | 110000-391 |
| R28 | 10 Ω , ±5%, 1/4 W Resistor | 110000-100 |
| R29 | 390 Ω , ±5%, 1/4 W Resistor | 110000-391 |
| R30 | 1.5 Ω , ±5%, 10 W, Wire-Wound Resistor | 116003-001 |
| R31 | 2.7 $k\Omega$, ±5%, 1/2 W Resistor | 110001-272 |
| R32 | 4.7 $k\Omega$, ±5%, 1/2 W Resistor | 110001-472 |
| R33 | 100 Ω , ±5%, 1/4 W Resistor | 110000-101 |
| R34 R35 | 91 Ω , ±5%, 1/4 W Resistor 22 Ω , ±5%, 1 W Resistor | 110000 - 910 110009 - 220 |

| R36 R37 | 15 Ω , ±5%, 1/4 W Resistor 22 Ω , ±5%, 1 W Resistor | 110000-150 110009-220 |
|------------------------------------|--|--|
| R38 R39 R40, R41 R42, R43 | 820 Ω, ±5%, 1/4 W Resistor 1.2 kΩ, ±5%, 1/2 W Resistor 750 kΩ, ±5%, 1/4 W Resistor 680 Ω, ±5%, 1/2 W Resistor | 110000-821 110001-122 110000-754 110001-681 |
| R44 R45 R46 R47 | 1.6 k Ω , ±5%, 1/2 W Resistor 22 Ω , ±5%, 1 W Resistor 680 Ω , ±5%, 1/4 W Resistor 15 Ω , ±5%, 1/4 W Resistor | 110001-162 110009-220 110000-681 110000-150 |
| R48 R49 R50 R51 | 22 Ω , ±5%, 1 W Resistor 1 $k\Omega$, ±5%, 1/4 W Resistor 1.2 $k\Omega$, ±5%, 1/4 W Resistor 3.9 $k\Omega$, ±5%, 1/4 W Resistor | 110009-220 110000-102 110000-122 110000-392 |
| R52 R53 R54 R55 | 22 kΩ, ±5%, 1/4 W Resistor 2.2 kΩ, ±5%, 1/4 W Resistor 2 kΩ, Horizontal Trimming Potentiometer (FREQ ADJ) 2.2 kΩ, ±5%, 1/4 W Resistor | 110000-223 110000-222 119002-202 110000-222 |
| R56 R57 R58 R59 | 470 Ω , ±5%, 1/4 W Resistor 4.7 $k\Omega$, ±5%, 1/4 W Resistor 2.2 $k\Omega$, ±5%, 1/4 W Resistor 39 Ω , ±5%, 1/4 W Resistor | 110000-471 110000-472 110000-222 110000-390 |
| R60 R61 R62 | 33 kΩ, ±5%, 1/4 W Resistor 1 kΩ, ±5%, 1/4 W Resistor 20 kΩ, Horizontal Trimming Potentiometer (HV OVER-VOLTAGE ADJ) | 110000-333 110000-102 119002-203 |
| R63 R64, R65 W1-W32 | 560 Ω , ±5%, 1 W Resistor 50 Ω , ±5%, 5 W Resistor 0 Ω Resistor | 110009-561 116001-500 110005-001 |
| | Transistors | |
| Q1 Q2 Q3 Q4, Q5 | Type-2N3904, 350 mW, 60 V, NPN Switching Transistor Type-2N3906, 1 W ,40 V, PNP Transistor Type-2N3904, 350 mW, 60 V, NPN Switching Transistor Type-2N3906, 1 W ,40 V, PNP Transistor | 34-2N3904 33-2N3906 34-2N3904 33-2N3906 |
| Q6-Q8 Q9 Q10-Q12 Q13 | Type-2N3904, 350 mW, 60 V, NPN Switching Transistor Type-2N3906, 1 W, 40 V, PNP Transistor Type-2N3904, 350 mW, 60 V, NPN Switching Transistor 2 A, 100 V, PNP Medium Power Transistor MPSU57 | 34-2N3904 33-2N3906 34-2N3904 133008-001 |
| Q14 Q15 Q16 Q17, Q18 | Type-2N3716, 10 A, 80 V, NPN Power Transistor Type-2N3792, 10 A, 80 V, NPN Power Transistor 2 A, 100 V, Medium Power NPN Transistor MPSU07 Type-2N3904, 350 mW, 60 V, NPN Switching Transistor | 133006-001 133007-001 133003-001 34-2N3904 |

ATARI 13-Inch Color X-Y Display

| | Q19 Q20 Q21 Q22 | 2 A, 100 V, PNP Medium Power Transistor MPSU57 Type-2N3716, 10 A, 80 V, NPN Power Transistor Type-2N3792, 10 A, 80 V, NPN Power Transistor 2 A, 100 V, Medium Power NPN Transistor MP5U07 | 133008-001 133006-001 133007-001 133003-001 |
|----------|----------------------------|---|---|
| | Q25 Q26 Q27 | Type-2N3904, 350 mW, 60 V, NPN Switching Transistor 2 A, 100 V, Medium Power NPN Transistor MP5U07 Type-2N3904, 350 mW, 60 V, NPN Switching Transistor | 34-2N3904 133003-001 34-2N3904 |
| | | Miscellaneous | |
| | | Thermally Conductive Compound Thermally Conductive Silicon Insulator Nylon Snap-In Fastener Nylon Shoulder Washer | 78–16001 78–16014 81–4302 175000–002 |
| | | Mica Insulator, TO-3 Preformed Silicon Boot Insulator Mica Insulator, TO-220 Grommet Strip | 178062-001 178064-001 178109-001 178113-001 |
| | | Fuse Clip Heat Sink High-Voltage Cage Cover | 179050-002 201019-01 201073-01 |
| A | F1, F2 F3, F4 | 5 A, 250 V, 3AG Slow-Blow Glass Cartridge-Type Fuse 3 A, 250 V, 3AG Slow-Blow Glass Cartridge-Type Fuse | 46-2015002 46-2033002 |
| | J1 J2 J3 J4 J5 | 2-Position Header Connector 4-Position Header Connector 5-Position Header Connector Terminal, Fast-On Tab 9-Position Header Connector | 179069-002 79-58317 79-58318 17-9051-001 79-58319 |




Figure 7 Neck PCB Assembly

Neck PCB Assembly A201020-02 1

Capacitors


| C1-C3 C4 C5 C6 | 220 pF, 100 V Minimum, Mica Capacitor 0.0068 μF, +80%, -20%, 1 kV, Ceramic Capacitor 0.1 μF, ±20%, 400 V, Radial-Lead Mylar Capacitor 0.1 μF, +80%, -20%, 50 V, Ceramic Capacitor | 128002-221 120000-682 126002-104 122002-104 |
|--------------------------|--|--|
| | Inductors | |
| L1-L3 | 330 µH, ±10%, Inductor | 141009-001 |
| | Resistors | |
| R1 R2 R3 R4 | 2.2 kΩ, ±5%, 1/4 W Resistor 3.3 kΩ, ±5%, 1/4 W Resistor 1 kΩ, ±5%, 1/4 W Resistor 82 Ω, ±5%, 1/4 W Resistor | 110000-222 110000-332 110000-102 110000-820 |
| R5 R6 R7 R8 | 2.2 kΩ, ±5%, 1/4 W Resistor 10 kΩ, ±5%, 2 W Resistor 220 Ω, ±5%, 1/4 W Resistor 500 Ω Vertical Trimming Potentiometer (Red Drive) | 110000-222 110010-103 110000-221 119001-501 |
| R9 R10 R11 R12 | 3.9 kΩ, ±5%, 1/4 W Resistor 2.7 kΩ, ±5%, 1/2 W Resistor 10 kΩ, Vertical Trimming Potentiometer (Red Bias) 3.3 kΩ, ±5%, 1/4 W Resistor | 110000-392 110001-272 119001-103 110000-332 |
| R13 R14 R15 R16 | 1 kΩ, ±5%, 1/4 W Resistor 82 Ω, ±5%, 1/4 W Resistor 2.2 kΩ, ±5%, 1/4 W Resistor 10 kΩ, ±5%, 2 W Resistor | 110000-102 110000-820 110000-222 110010-103 |
| R17 R18 | 220 Ω , ±5%, 1/4 W Resistor 500 Ω Vertical Trimming Potentiometer (Green Drive) | 110000-221 119001-501 |
| R19 R20 | 3.9 kΩ, ±5%, 1/4 W Resistor 2.7 kΩ, ±5%, 1/2 W Resistor | 110000-392 110001-272 |
| R21 | 10 kΩ Vertical Trimming Potentiometer (Green Bias) | 119001-103 |
| R22 R23 R24 | 3.3 k Ω , ±5%, 1/4 W Resistor 1 k Ω , ±5%, 1/4 W Resistor 82 Ω , ±5%, 1/4 W Resistor | 110000-332 110000-102 110000-820 |
| R25 R26 | 10 k Ω , ±5%, 2 W Resistor 220 Ω , ±5%, 1/4 W Resistor | 110010 - 103 110000 - 221 |

ATARI 13-Inch Color X-Y Display

| R27 | 500 Ω Vertical Trimming Potentiometer | 119001-501 | |
|------------------------------------|--|--|--|
| R28 | (Blue Drive) 3.9 kΩ, ±5%, 1/4 W Resistor | 110000-392 | |
| R29 R30 R31 R32 W1, W2 | 2.7 kΩ, ±5%, 1/2 W Resistor 10 kΩ Vertical Trimming Potentiometer (Blue Bias) 5 MΩ Vertical Trimming Potentiometer (Brightness) 10 MΩ, 1/2 W Resistor 0 Ω Resistor | 110001-272 119001-103 119001-505 110023-106 110005-001 | |
| | Transistors | | |
| Q1 Q2 Q3 | Type-2N3906, 40 V, 1 W, PNP Transistor Type-D40P5, 225 V, 0.5 A, NPN Transistor Type-2N3904, 60 V, 350 mW, NPN Switching Transistor | 33-2N3906 133009-001 34-2N3904 | |
| Q4 | Type-2N3906, 40 V, 1 W, PNP Transistor | 33-2N3906 | |
| Q5 Q6. | Type-D40P5, 225 V, 0.5 A, NPN Transistor Type-2N3904, 60 V, 350 mW, NPN Switching Transistor | 133009-001 34-2N3904 | |
| Q7 | Type-2N3906, 40 V, 1 W, PNP Transistor | 33-2N3906 | |
| Q8 Q9, Q10 | Type-D40P5, 225 V, 0.5 A, NPN Transistor Type-2N3904, 60 V, 350 mW, NPN Switching Transistor | 133009-001 34-2N3904 | |
| Miscellaneous | | | |
| J205 J9 J8 | 6-Position Header Connector Fast-On Tab Terminal 14-Position Header Connector | 179014-006 179051-001 79-58324 | |
| P1, P4 | CRT Socket Assembly Hazard Shield Nylon Snap-In Fastener | A201084-01 201052-01 81-4302 | |



Figure 8 Wiring Diagram






Figure 9 Deflection PCB Schematic Diagram




Figure 9 Deflection PCB Schematic Diagram, continued

